


# KLUDI BINGO STAR

42030



A\_4203078

42030	Waschtisch-Einhandmischer DN 10	single lever basin mixer DN 10	éengreeps wastafelmengkraan 3/8"
73 038	Hebel, KLUDI BINGO STAR	lever, KLUDI BINGO STAR	hendel, KLUDI BINGO STAR
74 266	PCA Cache-Luftsprudler M 16,5 x 1	PCA Cache aerator M 16,5 x 1	PCA Cache-perlator M 16,5 x 1
74 286	Zugstange	lift rod	trekstang
74 464	Befestigungssatz	assembling set	bevestigingsset
75 260	Ablaufgarnitur	pop up waste	afvoergarnituur
75 605	Kartusche	cartridge	cartouche
823 115	Spannschraube	screw	spanschroef
922 046	Gewindestift	threading lathe	inbus schroef
929 077	Armaturenschlüssel	fastening tool	sleutel
930 186	Abdeckkappe	cover cap	afdekkap
930 693	Schlüssel für Strahlregler	key for aerator	sleutel voor straalbreker
930 897	Markierungsstopfen	red/blue insert	markeringsstop