



| Model | A1 | A2 | X1 | X2 | Y1 | Y2 | B1 | B2 | C1 | C2 | D | H |
|----------------------|------|------|---------|---------|---------|---------|-----|-----|---------|---------|-----|------|
| KDD 80Lx80R | 800 | 800 | 789-797 | 789-797 | 776-784 | 776-784 | 530 | 530 | 263-271 | 263-271 | 745 | 2000 |
| KDD 80Lx90R | 800 | 900 | 789-797 | 889-897 | 776-784 | 876-884 | 530 | 630 | 263-271 | 263-271 | 810 | 2000 |
| KDD 80Lx100R | 800 | 1000 | 789-797 | 989-997 | 776-784 | 976-984 | 530 | 630 | 263-271 | 363-371 | 810 | 2000 |
| KDD 90Lx80R | 900 | 800 | 889-897 | 789-797 | 876-884 | 776-784 | 630 | 530 | 263-271 | 263-271 | 810 | 2000 |
| KDD 90Lx90R | 900 | 900 | 889-897 | 889-897 | 876-884 | 876-884 | 630 | 630 | 263-271 | 263-271 | 885 | 2000 |
| KDD 90Lx100R | 900 | 1000 | 889-897 | 989-997 | 876-884 | 976-984 | 630 | 630 | 263-271 | 363-371 | 885 | 2000 |
| KDD 100Lx80R | 1000 | 800 | 989-997 | 789-797 | 976-984 | 776-784 | 630 | 530 | 363-371 | 263-271 | 810 | 2000 |
| KDD 100Lx90R | 1000 | 900 | 989-997 | 889-897 | 976-984 | 876-884 | 630 | 630 | 363-371 | 263-271 | 885 | 2000 |
| KDD 100Lx100R | 1000 | 1000 | 989-997 | 989-997 | 976-984 | 976-984 | 630 | 630 | 363-371 | 363-371 | 885 | 2000 |