


Wariant LEWY  
Variant L

Wariant PRAWY  
Variant R

## ARTA KDJI FRONT

Arta KDJI Front	A1	X1	Y1	B	D	H
KDJI Front 80	800	795-801	773-779	720	710	2000
KDJI Front 90	900	895-901	873-879	820	810	2000
KDJI Front 100	1000	995-1001	973-979	920	910	2000



Wariant LEWY  
Variant L

Wariant PRAWY  
Variant R

## ŚCIANKA S1 / SIDEWALL S1

Arta S1	A2	X2	Y2
S1 80	800	792-802	773-783
S1 90	900	892-902	873-883
S1 100	1000	992-1002	973-983
S1 110	1100	1092-1102	1073-1083
S1 120	1200	1192-1202	1173-1183

